



### Changing a lid seal on a PANTHER P50 pump

- 1) Each lid is attached to the motor housing with 4 hex screws and corresponding nuts. Pay attention to the lid position (air filter facing the electronic box).
- 2) Unscrew all 4 screws and set aside the screws and corresponding nuts.
- 3) Carefully remove the lid.
- 4) Using a thin tool, remove the gasket from the groove.
- 5) Replace the gasket with a new one and reassemble.

For any questions or assistance, please call us at: +49 2623 900 290 or email us at: [info@wertair.com](mailto:info@wertair.com)

### Wechseln einer Deckeldichtung bei einer PANTHER P50 Pumpe

- 1) Jeder Deckel ist mit 4 Imbusschrauben und dazugehörigen Muttern mit dem Motorgehäuse verbunden. Achten Sie auf die Deckelposition (Luftfilter zur elektronischen Box).
- 2) Schrauben Sie alle 4 Schrauben auf und legen die Schrauben und die dazugehörigen Muttern zur Seite
- 3) Entnehmen Sie vorsichtig den Deckel
- 4) Mit einem dünnen Werkzeug können Sie die Dichtung aus der Vertiefung (Nut) entnehmen.
- 5) Den Dichtring durch einen neuen Dichtring ersetzen und wieder zusammenbauen.

Für Rückfrage und Hilfe rufen Sie uns an : +49 2623 900 290